




# Butterfly Kiss Operating Instructions

SKU 3074

This feminine vibe may be small and dainty, but it's anything but weak! The soft bulb at the tip is comfy for penetration and G-Spot stimulation. The butterfly clitoral tickler has fluttering wings and tantalizing antennae that transmit 3 ascending speeds of vibration. It's completely waterproof and oh-so-portable.

- 1 year warranty
- Length: 7.25 inches
- Insertable length: 3 inches
- Batteries: 2AAA (not included)
- Pure silicone with ABS plastic cap
- Not for use with silicone lubricants
- Provides G-Spot Stimulation
- Waterproof



## Operating



Press and hold to turn on. This initiates the first speed of vibration. Press and hold 2 additional times to increase to the accelerating 2 other vibrations. Press and hold again to turn off.

## Cleaning and storage

Clean before and after every use. Dry completely. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.) Store in a cool dry location.

## Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

## To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:

Remove batteries when not in use and store separately.

Do not store products near extreme cold or heat. Store in a cool, dry location.

Store products separately as different materials may react with each other.

Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and your furniture.

**Caution:** For adult use only as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

## Warranty

All sales are final due to the intimate nature of our products. No cash refunds will be given.

Effective February 1, 2021, this motorized product is guaranteed for 1 year for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item. All defective product returns must be accompanied by a pre-authorization number.

If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's, Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.



© June 2021

Athena's Home Novelties, Inc.  
Woonsocket RI 02895

www.athenashn.com  
1-877-ATHENAS

## Batteries

Twist the cap (counterclockwise) at the base to remove from the toy. Be sure to follow the + and - signs when inserting batteries. Snap and twist (clockwise) the cover to close. Be sure the cap is securely twisted back in place in place. Remove batteries and store separately after each use.



Press and hold to turn on. This initiates the first speed of vibration. Press and hold 2 additional times to increase to the accelerating 2 other vibrations. Press and hold again to turn off.