

Flashing Finger Operating Instructions



SKU 3043

Light up your next intimate encounter with our Flashing Finger Vibe! Not only can you caress the body to erotic bliss, you can illuminate your intimate play in a fun new way! Secure the vibe to your finger using the stretchy silicone ring. The raised nubbies provide extra pleasure texture. The one speed is controlled by an easy on/off button. Color may vary.

- Length: 2 inches
- Batteries: 3 LR44 (included)
- Waterproof
- Silicone Sleeve and ABS Plastic Bullet
- Not for use with silicone lubricants

Easy 1 button
control



Sure finger grip



Operating



Press for 3 seconds for
vibration and light.
Press again for 3 seconds
to turn off.

Cleaning and storage

Clean before and after every use. Dry completely. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.) Store in a cool dry location.

Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:

Remove batteries when not in use and store separately.

Do not store products near extreme cold or heat. Store in a cool, dry location.

Store products separately as different materials may react with each other.

Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces.

Place them on a cloth to protect your toys and your furniture.

Caution: For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain. This vibe is small enough to swallow. Use caution and keep out of reach for of children.

Warranty

All sales are final due to the intimate nature of our products. This Motorized product is guaranteed for 30 days for a replacement. No refunds will be given. If you receive a broken product, or if your product breaks within 30 days of receipt, please contact your distributor, if purchased at a party, or our Customer Care Liaison if purchased on our website, for instructions on how to send back your item for a replacement.

All defective product returns must be accompanied by a pre-authorization number. Our Customer Care Liaison can be reached by calling 1-877-ATHENAS or via email at E-mail: customerservice@athenashn.com



ATHENA'S
HOME NOVELTIES

© June 2021
Athena's Home Novelties, Inc.
Woonsocket RI 02895
www.athenashn.com
1-877-ATHENAS

Batteries

Unscrew bullet cap and remove battery protector before use.

Raised side is insert with the battery list facing out. Screw the lid back into place. Be sure the lid is securely in place.

Remove batteries when not in use and store separately.

Battery Compartment

