

# Hold Your Tongue Instructions



SKU3472


Thanks to thoughtful and innovative female designers and technological advancements, we bring you *Hold Your Tongue* – an exciting and satisfying pleasure device that mimics oral sex! *Hold Your Tongue* can lick – nipples, vulva, anus, frenulum – with a steady, consistent rhythm of 3 flickering speeds and 10 patterns of vibration. The silicone tongue is soft, flexible, and sensually textured. The handle makes it easy to Hold Your Tongue exactly where you want it. The illuminated buttons make changing speeds and functions easy. You can even live out an underwater fantasy! *Hold Your Tongue* is WATERPROOF! Pair with your favorite lube for a better and wetter experience

## Features

Insertable length: 3.5"  
 Total Length: 7.5"  
 Tongue width widest point: 1.50"

Rechargeable - charge conveniently with the USB cable included  
 Charge time: 2.5 hours  
 Run time: .75 hour on highest settings  
 Run time: 2.5 on low settings  
 State-of-the-art memory chip resumes on last function used  
 Flickering & Vibrating Shaft  
 Dual motor independent toy  
 3 speeds of independent shaft flicker  
 10 functions of independent vibration and pulsation and escalation  
 Security travel lock feature

Silicone with ABS plastic on handle  
 Latex and Phthalate free  
 Not for use with silicone lubricants  
 Waterproof



## Cleaning

Always clean product before first use, and clean after every use. For best results we recommend using Athena's (anti-microbial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.).

## Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

**To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:**

Do not store products near extreme cold or heat.

Store in a cool, dry location.

Store products separately as different materials may react with each other.

Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and your furniture.

## Warranty

All sales are final due to the intimate nature of our products. No cash refunds will be given.

Effective February 1, 2021, this motorized product is guaranteed for 1 year for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item. All defective product returns must be accompanied by a pre-authorization number.

If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's, Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.



© June 2021 Athena's Home Novelties, Inc. 1-877-ATHENAS

## Charging

Charge upon opening. Insert input plug at the back toward the base and connect the USB output plug to the USB port of your computer or other power source and the other end to the toy's input.


LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months.

**Complete charge time:** 2.5 hours  
**Run time on high:** .75 hour  
**Run time on low:** 2.5 hours

Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months.



## Control Panel



## OPERATING INSTRUCTIONS:

1. This item comes with a security lock feature. To unlock product, press and hold the top button for 3 seconds, you will see the bottom 2 buttons momentarily illuminate.
2. To activate flicker shaft feature, press the middle button. Tap button for 2 additional function levels.
3. To turn off special flicker feature at any time, press and hold the middle button for 3 seconds.
4. To activate vibrating functions in the pulsation and vibration action, press the bottom button once. Continue by tapping 9 more times until desired action is reached.
5. To turn off pulsation and vibration actions at any time, press and hold the bottom button for 3 seconds.
6. To turn off all special shaft features and vibrations in the stimulator at any time press the top button once.
7. To relock product, press and hold the top button for 3 seconds. Ensure product is locked after each use to conserve battery life.
8. This item comes with a memory feature; item will resume on last function used.