

Triple Goddess Operating Instructions



ATHENA'S
HOME NOVELTIES

SKU 3391

Your sexuality is sacred! This sturdy and smooth silicone wand is topped with three round, flexible and strategically placed points of contact that immerse the clitoris in mind-blowing trifection of rumbling vibration. The hole in tip can be used to turn a finger into a living vibrator or can be stretched around the hood of the clitoris. It's rechargeable! It's also the perfect size for a tongue to slide through for added ecstasy! The handle makes it easy to grip and apply light or firm pressure as you cycle through 20 speed settings, patterns and pulsations! It's rechargeable! It's waterproof! Make a splash and take it with you in the bath! It's rechargeable – no more batteries left behind on mother earth!

Features :

- Phthalate and Latex free
- Made of Silicone
- 20 Vibration and Pulsation Modes
- Length: 5.5"
- Width: 1.5"
- Colors May Vary
- Waterproof
- Rechargeable - USB cable included




Charging

Charge upon opening. Connect the USB cable to the USB port of an AC Adapter, your computer, or other power source and the other end to the toys input port.

The red light will be on when charging and turns off when fully charged. There is no danger of over-charging. Over 1 hour of playtime when on high speed.

Charge regularly every 1-2 months to preserve battery life.



Cleaning

Clean before and after every use. Dry completely. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.)

Store in a cool dry location.

Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:

Do not store products near extreme cold or heat. Store in a cool, dry location. Store products separately as different materials may react with each other. Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and your furniture.

Warranty

All sales are final due to the intimate nature of our products. No cash refunds will be given.

Effective February 1, 2021, this motorized product is guaranteed for 2 years for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item. All defective product returns must be accompanied by a pre-authorization number.

If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's. Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.

Caution

For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.



ATHENA'S
HOME NOVELTIES

www.athenashn.com

June©2021 Athena's Home Novelties, Inc.
Woonsocket, RI 02895 1-877-ATHENAS

Operating

To turn on or turn off press and hold the up or down button for 3 seconds. Pressing the buttons brings you to the first vibration. Press the up and down buttons to switch to other 19 modes of vibration and pulsation.

