

The All Nighter Operating Instructions




ATHENA'S
HOME NOVELTIES

SKU 3483

The All Nighter is a magnetic thrusting vibe that provides over-the-top orgasms. This thick and fulfilling silicone dual-action vibe is EXTREMELY powerful with a winged external stimulator that thumps against the body with an extraordinary toe-curling rhythm. With a curved G-spot head that reaches deeply and effortlessly, the 'thumping' action taps in just the right way to leave you breathless with pleasure! Choose from seven thrusting speeds to find the right intensity for you and three clitoral vibration speeds that will exceed your expectations, even underwater as it's completely waterproof and submersible. You may use it for just a few minutes, but it will feel like you've pulled an All Nighter when you're done!

Features :

Thumping
G-spot stimulation total length: 9.5 inches
Insertable length: 4.75 inches
Shaft width at largest point: 2.00 inches
Rechargeable - USB cable included
Waterproof and completely submersible
Phthalate and Latex free
Silicone and ABS plastic base
Not for use with silicone lubricants
Provides G-spot stimulation
Complete charge: 3 hours
Run time high speed: 40 minutes
Run time low speed: 120 minutes



Operating

Control Panel:


Tap the On/Off power key to start. The light at the bottom of control panel will glow.

Tap the power button to initiate the first of 3 clitoral patterns. Tap 2 more times for the additional patterns.

To initiate the shafts 7 thumping actions, tap the up ▲ button (top). Tap the up ▲ button (top) 6 more times for incremental thumping thrust actions. To reduce the thumping speeds, tap the down ▼ button (middle) 7 times. Each tap down will reduce the thumping thrust until the last tap.

Press the On/Off power key for 3 seconds at any time to completely disengage and turn off.

To engage/disengage the locking mechanism hold the on/off power key for 4 seconds. The item will thrust quickly to signal the locking/unlocking.



Cleaning and storage

Clean before and after use. Dry completely. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.)

Store in a cool dry location.

Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

Follow these simple steps to help extend the life cycle of your items

- Do not store products near extreme cold or heat.
- Do not store your adult toys in a manner where they are touching. Keep them separated to avoid melting or discoloring.
- Do not place lotion bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and the finish on your furniture.

Caution

For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

Warranty

All sales are final due to the intimate nature of our products. No cash refunds will be given. Effective February 1, 2021, this motorized product is guaranteed for 5 years for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item.

All defective product returns must be accompanied by a pre-authorization number. If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's. Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.



© June 2021
Athena's Home Novelties, Inc.
Woonsocket RI 02895
www.athenashn.com
1-877-ATHENAS

Charging

Charging

Charge upon opening. Connect the USB cable to the USB port of your computer or other power source and the other end to the toys input.

The LED light will glow when charging and turn off when fully charged. Initial charge takes about 3 hours. There is no danger of over-charging, but we recommend not to charge for long periods of time.

Complete charge: 3 hours

Run time high speed: 40 minutes

