

# The Right Touch Instructions



ATHENA'S  
HOME NOVELTIES

SKU 3437

This new dual stimulator provides pleasure while simultaneously strengthening the PC muscle! The smooth, curved silicone shaft is oh so flexible and designed to put pressure on the G-SPOT. The external stimulator is also silky, smooth and fantastically flexible with a wide tip for placement and pressure that is right for YOU! The Right Touch can be controlled using the buttons in the base OR you can utilize the "touch activation" option and use the vaginal muscles to turn it on and increase the speeds! Talk about a pleasurable workout! The 10 functions and 3 speeds are quiet yet rumbly for a satisfying encounter. When you want to make waves, take *The Right Touch* in the bath or shower with you! It's waterproof! USB charging cable included. Phthalate free.

Length: 8 inches  
Insertable length: 4 inches  
Width: 1.5 inches at widest point  
Rechargeable - USB Cable included  
Provides G-spot stimulation

Silky smooth silicone with ABS Plastic control panel  
Not for use with silicone lubricants  
Waterproof

Complete charge: 2.5 hours  
Run time high speed: 1.5 hours  
Run time low speed: 2 hours



4

## Cleaning

Clean before and after every use. Dry completely. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.) Store in a cool dry location.

## Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

## Follow these simple steps to help extend the life cycle of your toys

Do not store products near extreme cold or heat.

Store in a cool dry location.

Do not store your adult toys in a manner where they are touching. Keep them separated to avoid melting or discoloring.

Do not place lotion bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and the finish on your furniture.

## Warranty

All sales are final due to the intimate nature of our products. Motorized products are guaranteed for 30 days for a replacement. No refunds will be given. If you receive a broken product, or if your product breaks within 30 days of receipt, please contact your distributor, if purchased at a party, or our Customer Care Liaison if purchased on our website, for instructions on how to send back your item for a replacement. All defective product returns must be accompanied by a pre-authorization number.

Our Customer Care Liaison can be reached by calling (877) ATHENAS or via email at E-mail: customerservice@athenashn.com

## Caution

For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.




ATHENA'S  
HOME NOVELTIES

June ©2021  
Athena's Home Novelties, Inc.  
Woonsocket RI 02895  
1-877-ATHENAS

www.athenashn.com

1

## Operating



**Touch Mode:** Press Power Button (middle) for 3 seconds to turn ON. Light will glow. Touch or insert the shaft. 3 speeds of vibration will start and increase automatically. The first 5 seconds is low speed, the next 5 seconds progresses to the next speed and the last 5 seconds progresses to the highest speed. To go back to the first speed remove or release touch.

**Control Panel:** Press Power Button (middle) for 3 seconds to turn ON. Light will glow. Press the power button again to activate button control. Tap for each progression of the 10 functions.

To increase the vibration of each function press the + plus button and to decrease press the - minus button.


2

## Charging

**Charging:** Connect the USB cable to the USB port of your computer or other power source and the other end to the toys charging port.

The LED light will blink when charging and become solid when fully charged.

Complete charge: 2.5 hours  
Run time high speed: 1.5 hours  
Run time low speed: 2 hours



3