

Timeless Instructions

SKU 3442




The smooth, oval shaped vibrator is indeed an undeniable classic. Timeless connects the past with the present to bring you a sex toy that will deliver intense pleasure. The shaft is crafted with absolute perfection: smooth, silky silicone has a rounded and angled tip and a stylish metal accent at the base. The motor within is of superior strength. Explore the satisfying sensations of 10 functions internally or externally using the one touch button at the base. Timeless will arouse you time and time again! Colors may vary.

Length: 6.25 inches
Insertable length: 4.25 inches
Width: 1.25 inches

Rechargeable - Magnetic USB Cable included
10 powerful vibration and pulsation levels
Provides G-spot stimulation
Silky smooth silicone with ABS Plastic trim
Not for use with silicone lubricants
Phthalate free
Waterproof

Complete charge: 3.0 hours
Run time about: 3.0 hours



Cleaning

Clean before and after every use. Dry completely. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.) Store in a cool dry location.

Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

Follow these simple steps to help extend the life cycle of your toys

Do not store products near extreme cold or heat.

Store in a cool dry location.

Do not store your adult toys in a manner where they are touching. Keep them separated to avoid melting or discoloring.

Do not place lotion bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and the finish on your furniture.

Caution

For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

Warranty

All sales are final due to the intimate nature of our products. No cash refunds will be given.

Effective February 1, 2021, this motorized product is guaranteed for 1 year for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item. All defective product returns must be accompanied by a pre-authorization number.


If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's, Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.



June ©2021 Athena's Home Novelties, Inc. Woonsocket RI 02895
1-877-ATHENAS www.athenashn.com

Operating

On/Off: Press the button at the base for 3 seconds.
Tap button to progress through additional functions.



Charging

Connect the USB cable to the USB port of your computer or other power source and the other end to the toys charging port.

The product may be delivered partially charged but we recommend a full charging cycle before use.

Adhere the magnetic charger directly onto the two magnetic dots on the vibrator. The power lights at the base of the vibrator will remain solid when charging and blink when fully charged.

Complete charge: 2.0 hours
Run time about: 1.0 hour

