# **Tri-Oh Operating Instructions**



# **Operating**

Control Panel: Press the On/Off key to start. The colored lights at the base on the control panel will turn on. The first vibration function will start. Press the On/Off key for On and to cycle through the vibrations from all 3 elements to the shaft and butt tickler and the clitoris stimulator, then to the butt tickler shaft and clitoris stimulator. Press on the vibration button to cycle through the eight function of pulsations.



# Charging

Charge upon opening. Connect the USB cable to the USB port of your computer or other power source and the other end to the toys input. The LED light will blink when charging and become solid when fully charged. Initial charge takes about 4 hours. There is no danger of over-charging.



# Cleaning and storage

Clean before and after use. Dry completely. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.) Store in a cool dry location.

## Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

## Follow these simple steps to help extend the life cycle of your items

Do not store products near extreme cold or heat.

Do not store your adult toys in a manner where they are touching. Keep them separated to avoid melting or discoloring.

Do not place lotion bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and the finish on your furniture.

## Caution

For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

#### Warranty

All sales are final due to the intimate nature of our products. No cash refunds will be given.

Effective February 1, 2021, this motorized product is guaranteed for 5 years for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item. All defective product returns must be accompanied by a pre-authorization number.

If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's, Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.

### **Features**

Rechargeable - charge conveniently with the USB cable included

8 powerful functions and vibrations

Latex and Phthalate free

Shaft length: 8.75 inches

Shaft Insertable length: 4.75 inches, Width 1.75 inches

Clitoral Stimulator Length: 2 inches

Anal tickler length: 3.25 inches - Width: 0.75inches

Silicone with ABS plastic handle

Not for use with silicone lubricants

Waterproof

Provides G-spot stimulation

## Caution

For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.



©June 2021 Athena's Home Novelties, Inc. 640 Winter Street, Woonsocket RI 02895 www.athenashn.com 1-877-ATHENAS