

# Trifecta Operating Instructions



SKU 3485



Good things come in THREES! This easy to hold massager is stylish with a rose gold handle that makes it simple to apply just the right pressure to your erogenous zones! Three high powered speeds of vibration, 7 functions and three different tips will allow you to experience a customized indulgent orgasm. The three interchangeable, silicone Trifecta tips are luxuriously smooth and include a scoop, a bulb and a U-shaped tickler! For a little wet and wild fun, pick your favorite tip and head to your bath or shower! Start or finish your day with the Trifecta of pleasure!

## Features :

- Pure silicone with ABS plastic handle
- Phthalate free
- Total length: 3.75"
- Attachment size: 2"
- Waterproof
- Not for use with silicone lubricants
- Rechargeable - charge conveniently with the USB cable included
- Charge time: 60 minutes
- Run time: 45 minutes
- 3 speeds & 7 functions of vibration



## Cleaning

Always clean product before and after every use. For best results we recommend using Athena's (anti-microbial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.)

## Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

**To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:**

Do not store products near extreme cold or heat.

Store in a cool, dry location.

Store products separately as different materials may react with each other.

Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and your furniture.

**Caution:** For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

## Warranty

All sales are final due to the intimate nature of our products. No cash refunds will be given. Effective February 1, 2021, this motorized product is guaranteed for 5 years for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at [customerservice@athenashn.com](mailto:customerservice@athenashn.com) for instructions to send back your item.

All defective product returns must be accompanied by a pre-authorization number.

If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's, Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.




June ©2021  
Athena's Home Novelties, Inc.  
Woonsocket, RI 02895  
1-877-ATHENAS

## Charging

Charge upon opening. Insert input plug at the base and connect the USB output plug to the USB port of your computer or other power source and the other end to the toy's input.

LED light will flash while charging and glow solid when fully charged. Fully charge product before use. We recommend fully charging your product once every 6 months.

Charge time: 60 minutes  
Run time: 45 minutes



## Operating

OPERATING INSTRUCTIONS:

1. Select desired tip. Turn clockwise to secure tip to handle.
2. To remove tip, turn counterclockwise.
3. Press and hold the power button for 3 seconds to initiate first speed.
4. Continue escalations by tapping power button until desired speed/function is reached.
5. To turn off press and hold the power button for 3 seconds.

