

Wave Length

SKU 3478




This stylish, rechargeable joy toy is on your Wave Length! It has a wavy design along the length of its curvy, flexible, creamy, silicone shaft. Let shivers run down your spine when the external thumb-shaped vibe puts pressure on the sweetest of sweet spots! The two powerful motors operate independently allowing you to customize your experience with 10 vibrating speeds and functions. The black chrome finish encases the control panel of 3 easy to use illuminated LED buttons. Enjoy waves of pleasure in your next steamy shower or bubble bath as it is completely submersible.

Features :

- Total length: 8.25"
- Insertable length: 5.5"
- Shaft width at largest point: 1.59"

- Flexible shape moves with body
- Dual-action massager with 2 powerful independent motors
- Silicone with ABS plastic on handle
- Latex and Phthalate free
- Not for use with silicone lubricants
- Waterproof
- Provides G-spot stimulation

- Rechargeable - charge conveniently with the USB cable included
- Charge time: 2.5 hours
- Run time: 1.5 hours on highest settings
- Run time: 3.0 hours on low settings
- Both motors run time: 1.0 hour on highest settings
- Both motors run time: 2.0 hours on low settings



Cleaning

Always clean product before first use, and clean after every use. For best results we recommend using Athena's (anti-microbial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.)

Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:

Do not store products near extreme cold or heat.

Store in a cool, dry location.

Store products separately as different materials may react with each other.

Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and your furniture.

Caution

For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

Warranty

All sales are final due to the intimate nature of our products. No cash refunds will be given.

Effective February 1, 2021, this motorized product is guaranteed for 5 years for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item. All defective product returns must be accompanied by a pre-authorization number.

If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's, Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.



ATHENA'S
HOME NOVELTIES

www.athenashn.com

June ©2021
Athena's Home Novelties, Inc.
Woonsocket RI 02895
1-877-ATHENAS

Charging


Comes partially charged. Fully charge upon opening. Insert input plug at the back of toy and connect the USB output plug to the USB port of your computer or other power source and the other end to the toy's input.

LED light will flash while charging and glow solid when fully charged. There is no danger of overcharging, but we recommend you do not overcharge for long period of time. Fully charge your product once every 6 months.

- Charge time: 2.5 hours
- Run time: 1.5 hours on highest settings
- Run time: 3.0 hours on low settings
- Both motors run time: 1.0 hour on highest settings
- Both motors run time: 2.0 hours on low settings



Control Panel



OPERATING INSTRUCTIONS:

1. Easy three-button control panel. Each button will glow as activated by pressing.
2. Press center button for 3 second to turn ON or Off.
3. Tap top button for shaft speed and functions. Tap to continue for additional 9 speeds and functions.
4. Tap bottom button for clitoral external speed and functions. Tap to continue for additional 9 speeds and functions.