Center of Attention Operating Instructions



SKU 3369

www.athenashn.com

This silky smooth, silicone penis ring is stretchy and comfortable to wear while making an erection the center of attention! The curved stimulator is elegantly designed to align with a partner's sensitive hot spots for simultaneous sensations. The pleasure ridges target the clitoris or perineum, depending on how you choose to play and assures a deeply satisfying ride at the partner-contact point. Lovers will enjoy exploring 7 escalating modes of rhythmic pulsation and vibration.

Features

Memory chip resumes on last speed use
Waterproof - with self-sealing charging port button
Rechargeable: USB charge cord included
Not for use with silicone lubricants
Ring: 100% Silicone
Silver shell: ABS Plastic
Phthalate free
Height: 3 inches
Width widest point: 1.75 inches
Diameter ring relaxed: 1 inch

Charge time: 70 minutes

Run time: High Speed approximately 55 minutes Run time: Low Speed approximately 80 minutes



Caution: For all erection rings

This non-medical device is intended as a sexual enhancing aid only. Not intended for contraceptive/birth control or the treatment of erection conditions. Use no longer than 30 minutes at a time. Allow 60 minutes between additional uses. Do not fall asleep or fall asleep under the influence of alcohol or drugs while using this product. Prolonged use (without removal) may result in bruising at the base or permanent injury to the penis. Consult a physician should any complication occur and discontinue use immediately.

Cleaning and storage

Clean, before and after every use. Dry completely. For best results, we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.)

Store in a cool dry location.

Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

Follow these simple steps to help extend the life cycle of your items

Do not store products near extreme cold or heat.

Do not store your adult toys in a manner where they are touching. Keep them separated to avoid melting or discoloring.

Do not place lotion bottles or adult novelties directly on furniture surfaces.

Place toys on a cloth to protect your toys and the finish on your furniture.

Warranty

All sales are final due to the intimate nature of our products. No cash refunds will be given.

Effective February 1, 2021, this motorized product is guaranteed for 1 year for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item. All defective product returns must be accompanied by a pre-authorization number.

If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's, Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.



© June 2021 Athena's Home Novelties, Inc. Woonsocket RI 02895 www.athenashn.com 1-877-ATHENAS


Charging

Charge prior to use. Connect the USB cable to the USB port of your computer or other power source and the other end to the toys input port.

The light will flash while charging and become solid light when fully charged.

Initial charge: 70 minutes Run time: High speed approximately 55 minutes Run time: Low speed approximately 80 minutes





Operating: To turn on or turn off, hold power buttom down for 3 seconds. Tap the On/Vibration button to cycle through the 6 additional modes of vibration and pulsation. Tap for 3 seconds for Off. This toy resumes operation to the last mode used.

Tap On 3 seconds / Tap for 6 additional modes of vibration / Tap 3 seconds Off

