

In-Oh-vator Instructions



ATHENA'S
HOME NOVELTIES

SKU 3496

Introducing another miraculous stride forward in orgasmic inducing technology. Unlike suction and classic vibes, this dual stimulator provides a tapping sensation that will send a clitoris into orbit! Made of a velvety soft and body-safe silicone, In-Oh-vator can be used as an easy to hold wand. For a completely different experience, simply bend the handle and insert the smooth shaft into the body. It's adjustable to help find your most comfortable angle while the tapping tip simultaneously and rhythmically massages externally. And the beat goes on and on with 10 clit-focused pressure waves and tingling pulsation patterns. 10 vibration modes apply up to 8,000 mind-scrambling vibrations per minute. The In-Oh-vator is waterproof so take those revolutionary tapping sensations underwater for an explosive encounter in the shower or bath.

Features :

- 6 Month Warranty
- 100% smooth silicone and ABS plastic metallic plating trim
- Phthalate free
- Provides G-spot stimulation
- Waterproof
- Not for use with silicone lubricants
- Rechargeable USB charge cord included
- Charge time: 2.5 hours
- Run time low speed: 90 minutes
- Run time high speed: 50 minutes
- Length: 8"
- Insertable length: 3.75"
- Width: 2"



Cleaning

Always clean product before every use, and clean after every use. For best results we recommend using Athena's (anti-microbial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.).

Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer SKU 5701. Not for use with silicone lubricants.

To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:

Do not store products near extreme cold or heat. Store in a cool, dry location. Store products separately as different materials may react with each other. Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and your furniture.

Caution: For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

Warranty

All sales are final due to the intimate nature of our products. No cash refunds will be given.

Effective February 1, 2021, this motorized product is guaranteed for 6 months for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item. All defective product returns must be accompanied by a pre-authorization number.

If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's, Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.



ATHENA'S
HOME NOVELTIES

© September 2021
Athena's Home Novelties, Inc.
Woonsocket RI 02895
www.athenashn.com
1-877-ATHENAS

Operating


Both motors start and stop independently.

Clitoral stimulation modes: Top Button

Press and hold the top button for 2 seconds to activate waves and patterns. The button will glow when On. Tap to initiate the 9 additional functions. Each tap will cycle to the next intensity level. Press for 2 seconds to turn off.

Toy vibration modes: Bottom Button

Press and hold the bottom button for 2 seconds to activate vibrations and patterns. The button will glow when On. Tap to initiate the 9 additional functions. Each tap will cycle to the next intensity level. Press for 2 seconds to turn off.



Charging



Charging:

Fully charge product before first use. Insert input plug located below the 2 operating buttons. Connect the USB output plug to the USB port of your computer or other power source and the other end to the toy's input.

Lights will flash while charging and glow solid when fully charged. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months.

Charge time: 2.5 hours
Run time low speed: 1.5 hours