

# Twice as Nice Instructions

SKU 3509



What's not to love about a double-sided pleasure device that treats the clitoris to sensations that are Twice as Nice? One silky, silicone side focuses on stimulating the clitoris with 8 modes of indirect bursts of air that mimic suction. The other side gives the user even more choices! The wand style tip comes with 2 smooth silicone attachments to customize your orgasm with precise, pinpoint vibration. Choose your tip and explore 8 functions of vibration, escalation and pulsation. Experience twice the fun and twice the pleasure in and out of water!

## Features :

- 5 year warranty
- 2 Independent motors
- Waterproof
- Phthalate and Latex free
- Silicone and ABS plastic trim and tip
- Not for use with silicone lubricants
- Total length: 8.00"
- Width at widest point: 1.76"
- Rechargeable - USB magnetic charge cord included
- Complete charge: 2 hours
- Run time high speed: 1 hour



## Operating



**Control Panel:** Each button is designed to be used independently.

**TIP VIBRATION:** You may choose to easily snap on the sphere or the tulip attachment to customize excitement and sensations. Press the Tip Vibration button (nearest the tip) for 3 seconds to start. The button light on the control panel will glow. Tap the Tip Vibration button to cycle through the 7 additional modes. Press Tip Vibration button (nearest the tip) for 3 seconds to stop.

**SUCTION AIR PULSE:** Press Suction air pulsing button (nearest the suction device) for 3 seconds to start. The button light on the control panel will glow. Tap the Suction air pulsing button to cycle through the 7 additional modes. Press the Suction air pulsing button (nearest the suction device) for 3 seconds to stop.

## Cleaning and storage:

Clean before and after use. Dry completely. Be sure to remove the clitoral tip to clean and then store the tips unattached from the toy. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.).

## Lubrication:

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

Follow these simple steps to help extend the life cycle of your items:

Do not store products near extreme cold or heat.

Do not store your adult toys in a manner where they are touching. Keep them separated to avoid melting or discoloring.

Do not place lotion bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and the finish on your furniture.

Store in a cool dry location.

## Caution :

For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

## Warranty:

All sales are final due to the intimate nature of our products. No cash refunds will be given.

Effective February 1, 2021, this motorized product is guaranteed for 5 years for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item.

All defective product returns must be accompanied by a pre-authorization number. If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's, Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.



©January 2022  
Athena's Home Novelties, Inc.  
Woonsocket RI 02895  
www.athenashn.com  
1-877-ATHENAS

## Charging

This vibrator arrives with a partial charge. Fully charge before first use. Connect the USB cable to the USB port of your computer or other power source and align the magnetic dots of the charge cord to the magnetic dots on the toy. The light on the control panel will flash when charging and remain solid when fully charged. Full charge takes about 2 hours. There is no danger of over-charging, but we recommend not to charge for long periods of time. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months.

Rechargeable - USB magnetic charge cord included

Complete charge: 2 hours

Run time high speed: 1 hour

