

Shake, Rattle & OHHH Instructions

SKU 3529



Enjoy the rapture of vigorous in and out motions with this high-powered thruster! Versatile for every body, use it vaginally to stimulate the G-spot or anally to hit the P-spot! 2 motors work in unison to create 10 thumping speeds in the rigid silicone shaft and 10 levels of vibration functions in the flexible external stimulator. With a 25-foot range, the optional wireless remote allows you to turn your lover on across the table or across the room! Shake, Rattle & OHHH will rock your world with extraordinary sensations underwater, between the sheets or anywhere you desire!

Features :

- 5 Year Warranty
- Toy: Total Length: 5.36", Insertable Length: 4", Width : 1.6"
- Remote: Length: 2.36", Width: 1.5"
- Waterproof and submersible
- Phthalate and latex free
- Toy: Silicone Remote: ABS plastic
- Dual motors operate in unison
- Not for use with silicone lubricants
- Provides G-spot stimulation
- Can be used with or without the remote
- Toy: Rechargeable USB charge cord included
- Wireless Remote Control included
- Remote battery: 1 CR2032 included

Optional Remote 25 Foot Range



10 functions Thrusting shaft

Sculptural textures throughout

10 functions Stingray shaped feeler

Power Button at Base

Replace remote battery

Slide battery compartment to the right as indicated by the arrow. Remove old battery and slip new battery + side up into compartment. Slide cover back into place



Charging

Indicator light will flash when charging and glow solid when complete. Connect to a USB power source.



Toy charging: This vibrator arrives with a partial charge. Charge completely prior to first use. Connect the USB cable to the USB port of your computer or other power source and insert the charging cord directly onto the toy.

The light on the control panel will flash when charging and remain solid when fully charged. Full charges take about 3 hours. There is no danger of over-charging, but we recommend not to charge for long periods of time. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Only use the cord supplied with this product or an Athena's authorized replacement cord.

Complete charge: 3 hours
Run time high speed: 1 hour
Run time low speed: 2 hours

Cleaning and storage:

Clean before and after use. Dry completely. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.)

Lubrication:

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

Follow these simple steps to help extend the life cycle of your items:

Remove batteries when not in use and store separately.

Do not store products near extreme cold or heat.

Do not store your adult toys in a manner where they are touching. Keep them separated to avoid melting or discoloring.

Do not place lotion bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and the finish on your furniture.

Store in a cool dry location.

Caution :

For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

Warranty:

All sales are final due to the intimate nature of our products. No cash refunds will be given.

This motorized product is guaranteed for 5 years for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item.

All defective product returns must be accompanied by a pre-authorization number. If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's, Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.




©May 2022

Athena's Home Novelties, Inc.
Woonsocket RI 02895

www.athenashn.com
1-877-ATHENAS

Operating



This toy must be turned on with the button directly on toy. Once toy is on, it can be operated with the same power button directly, or with the remote control.

To operate toy directly without remote: Turn the toy on by pressing the Power Button at the base of the toy for at 3-4 seconds. The toy will enter standby mode. Tap the same Power Button to activate both motors and cycle through 10 speeds and functions of vibration. Turn the toy off by pressing the Power Button for 3-4 seconds. If left on standby, the toy will automatically turn on between 7 and 11 minutes.

To operate with remote control: Turn on the remote control by pressing the Power Button for 3-4 seconds. Then turn the toy on by pressing the Power Button at the base of the toy for 3-4 seconds, which puts it in standby. Once the toy motor is engaged and in standby, tap the plus or minus buttons on the remote to cycle through 10 speeds and functions of vibration in both motors. Turn the remote control off by pressing the Power Button for at least 3 seconds. If left on standby, the toy will automatically turn on between 7 and 11 minutes. Be sure to turn off the toy to completely disengage.

Anal Play Note: The anus is one of the most sensitive orifices of the human body and it is usually the one least mentioned, despite the fact, that gentle probing of the anus can bring men and women intense pleasure. Be daring and experience erotic pleasures and a wonderful feeling of sexual elation.

The rectal sphincter is extremely sensitive and should be stimulated with care. To ensure you have a healthy, safe and pleasurable experience, be sure to use an ample amount of lubrication and remember never to insert anything into the vagina after it has been in the rectum without thoroughly washing it first!