

Secret Seduction Instructions




SKU 3537



Secret Seduction is here to discreetly tease you AND please you. Secure the contoured silicone stimulator to a thong style panty using the magnetic wing tabs. Once in place, the hands-free seduction begins. Thanks to the compact, one-touch wireless remote control, you can experience 12 functions of varying vibration and sensual suction coming from 2 motors. Hand the remote to your partner and let the games begin! They will have the power to control your pleasure from up to 32 feet away! Adventurous couples can take their secret sexual shenanigans anywhere they choose, even underwater! Just keep the remote on dry land! It even has a memory chip to remember the last function used! It knows what you like!

Features :

- 1 Year Warranty
- Toy: Total Length: 4.50", Width : 1.5"
- Remote: Length: 3.00", Width: 1.50"
- Waterproof: Toy
- Splash proof: Remote
- Phthalate and latex free
- Toy: Silicone and ABS with Silver Plating (button, magnetic backing)
- Remote: ABS with PU cote
- Not for use with silicone lubricants
- Can be used with or without the remote
- Rechargeable USB dual pronged charge cord included



Powerful Sensual Suction



Charging



Indicator lights will flash when charging and glow solid when complete. Connect to a USB power source.

This vibrator arrives with a partial charge. Charge completely prior to first use. Connect the USB cable to the USB port of your computer or other power source and insert the plugs of the charge cord into the toy and remote.

The lights will flash when charging and remain solid when fully charged. Full charges take about 1.50 hours. There is no danger of over-charging, but we recommend not to charge for long periods of time. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Only use the cord supplied with this product or an Athena's authorized replacement cord.

- Complete charge: 1.50 hours
- Run time high speed: 40 minutes
- Run time low speed: 45 minutes

Cleaning and storage:

Clean before and after use. Dry completely. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.)

Lubrication:

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

Follow these simple steps to help extend the life cycle of your items:

- Do not store products near extreme cold or heat.
- Do not store your adult toys in a manner where they are touching. Keep them separated to avoid melting or discoloring.
- Do not place lotion bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and the finish on your furniture.
- Store in a cool dry location.

Caution :

For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

Warranty:


All sales are final due to the intimate nature of our products. No cash refunds will be given. This motorized product is guaranteed for 1 year for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item.

All defective product returns must be accompanied by a pre-authorization number. If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's, Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.



©August 2022
Athena's Home Novelties, Inc.
Woonsocket RI 02895
www.athenashn.com
1-877-ATHENAS

Operating



This toy must be turned on with the button (XO) directly on toy. Once toy is on, it can be operated with the same power button directly, or with the remote control. Memory chip resumes on last function used.

To operate toy directly without remote:

Turn the toy on by pressing the Power Button at the back (magnetic panel side) of the toy for 3-4 seconds. The toy will enter standby mode and the small indicator light above the power button will flash. Tap the same Power Button to activate both motors and cycle through 12 speeds and functions of vibration and suction. Turn the toy off by pressing the Power Button for 3-4 seconds. Toy will automatically deactivate after 30 minutes of inactivity.

To operate with remote control:

Turn the toy on by pressing the Power Button at the back of the toy (magnetic panel side) for 3-4 seconds, which puts it in standby. Turn on the remote control by pressing the Power Button (XO) for 3-4 seconds. This will initiate toy functions. Tap the Power Button (XO) on the remote to cycle through the additional 11 speeds and functions of vibration and suction. Turn the remote control off by pressing the Power Button for at least 3 seconds. Be sure to deactivate the toy too after each use to preserve the product's internal battery life.