

Upbeat Operating Manual


SKU 3550



Put yourself in a cheerful mood with *Upbeat* - a silky-smooth silicone vibe with thumping action! Feel the beat inside you when the perfectly curved and textured head slips inside the body. The surging head features 7 escalating, pulsating functions. Next, activate the independently controlled bunny-eared external tickler and cycle through 10 pleasure functions. As if 2 motors weren't enough, we added a third independent motor in the middle with its own 10 functions of vibration. Engage all 3 motors and *Upbeat* will bring you to the exquisite climax you were looking for. Take it with you into the shower for waterproof exploration of your erogenous zones.

Features :

- 1 Year Warranty
- Toy: Length: 9"
- Insertable length: 5"
- Width: 1.25"
- Waterproof
- Phthalate and latex free
- Toy: Silicone Trim: ABS plastic
- Three independent motors
- Not for use with silicone lubricants
- Provides G-spot stimulation
- Rechargeable magnetic USB charge cord included
- Complete charge: 2.5 hours
- Run time high speed: 1 hour



Cleaning and storage:

Clean before and after use. Dry completely. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-2762)

Lubrication:

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog.

Follow these simple steps to help extend the life cycle of your items:

- Do not store products near extreme cold or heat.
- Do not store your adult toys in a manner where they are touching. Keep them separated to avoid melting or discoloring.
- Do not place lotion bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and the finish on your furniture.
- Store in a cool dry location.

Caution :

For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.


Warranty:

All sales are final due to the intimate nature of our products. No cash refunds will be given. This motorized product is guaranteed for 1 year for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com.



© April 2023
Athena's Home Novelties, Inc.
Woonsocket RI 02895
www.athenashn.com
1-877-ATHENAS

Charging




Indicator light will flash when charging and glow solid when complete.

This vibrator arrives with a partial charge. Charge completely prior to first use. Connect the USB cable to the USB port of your computer or other power source and align the magnetic dots on the cord to the 2 magnetic dots on the back of the toy.

The light on the control button (in front) will flash when charging and remain solid when fully charged. There is no danger of over-charging, but we recommend not to charge for long periods of time. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Only use the cord supplied with this product or an Athena's authorized replacement cord.

Complete charge: 2.5 hours
Run time high speed: 1 hour

Operating



MIDDLE BUTTON: Turn the toy ON by pressing the Power Button (middle button) of the toy for at 3 seconds. The button will illuminate and enter standby mode.

MIDDLE BUTTON: Tap the same Power Button to activate and cycle through 10 speeds and functions of middle vibrations.

TOP BUTTON: Activate the 7 thumping G-spot actions by tapping the top button and continue tapping for additional actions.

BOTTOM BUTTON: Activate the 10 rabbit ear vibrations by tapping the (bottom button) and continue tapping for additional vibrations.

MIDDLE BUTTON: Turn the toy OFF by pressing the Power Button (middle button) of the toy for 3 seconds.